

If you are using a printed copy of this procedure, and not the on-screen version, then you MUST make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A.

C-A OPERATIONS PROCEDURES MANUAL

ATTACHMENT

4.100.a Roof Access Requirements

C-A-OPM Procedures in which this Attachment is used.		
4.100		

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: _____ ***Signature on File*** _____
 Collider-Accelerator Department Chairman Date

A. Etkin

ROOF ACCESS REQUIREMENTS

Building	Access Control	RHIC Operational	RHIC Non-Operational
1002A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1002B	Locked Fence Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1002C		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1002D		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1004A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1004B		Work Planning/ Work Permit	Work Planning/ Work Permit
1005E		Work Planning/ Work Permit	Work Planning/ Work Permit
1005H		Work Planning/ Work Permit	Work Planning/ Work Permit
1005P		Work Planning/ Work Permit	Work Planning/ Work Permit
1005R		Work Planning/ Work Permit	Work Planning/ Work Permit
1005S		Work Planning/ Work Permit	Work Planning/ Work Permit
1006- Assembly Building Section	Berm Fence Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1006A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1006B		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1006C		Work Planning/ Work Permit	Work Planning/ Work Permit

1006D		Work Planning/ Work Permit	Work Planning/ Work Permit
1007W		Work Planning/ Work Permit	Work Planning/ Work Permit
1008 – Assembly Building Section	Berm Fence Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1008A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008A – Counting House	Locked Fence Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1008B		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008C		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008D		Work Planning/ Work Permit	Work Planning/ Work Permit
1008E		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1010A	Locked Ladder	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1010B		Work Planning/ Work Permit	Work Planning/ Work Permit
1012A	Locked Fence Locked Ladder	(Beam must be disabled for access to ladder) RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1101		Work Planning/ Work Permit	Work Planning/ Work Permit