

Instrumentation Group Procedure C-A-INT-001
Original Issue Date: 01/10/02
Revision 02

CHECKLIST FOR ENTERING “THE PIT”
WHEN USING SOURCES

* This checklist procedure is to be used by Authorized Source Operators only *

- 1) Authorized Source Operator must
 - a. Obtain approved work plan.
 - b. Posses proper training.
 - c. Sign in using appropriate RWP .

- 2) Obtain the appropriate source keys from the Instrumentation Group Key Box or access Controls Group Key Box and fill out the key log appropriately.

- 3) Verify that the Calibration Pit is ready for usage.

- 4) Authorized Source Operator must be wearing TLD and SRD.

- 5) Upon entering the Calibration Pit the following must be observed:
 - a. The proper postings are in place.
 - b. The door is secured.
 - c. The Source Exposed light is on and operational.

AUTHORIZED SOURCE OPERATORS

NAME (PRINT)	NAME (SIGNATURE)	LIFE NUMBER