

Booster/AGS Ring Power Supply Systems
Group Procedure EPS-W-010
Revision 00

15.3.5.10 Procedure to Access the V102 Delay Scope Trigger in the Westinghouse

1. From spreadsheet
2. Controllers
3. AGS
4. CDC.911.WESTMG.V102
5. Then select "User By"
6. Page at the top of the page
7. User
8. Then set what user
9. The scope trigger is AMM.WEST.GEN3
10. To set pulse width

AMM.WEST.GEN3.CLK (CH # 8 OF V102 Chassis)

A) Set the setpoint to 500 counts with a 1 MHZ clock the pulse width will = 500 USEC.

11. To set the delay

AMM.WEST.GEN3.ST

A.) Set the setpoint to desired delay (Ex., for a 2.4 second delay set the setpoint to 2400000 counts x 1 USEC per count = 2.4 second Delay)