

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are available by contacting the **ESSHQ Procedures Coordinator, Bldg. 911A***

C-A OPERATIONS PROCEDURES MANUAL

(Collider Electrical Power Supply Group Procedure CPS-007)

Note: This document was formerly a C-A Group Procedure. The content of the group procedure was reviewed by the Technical Supervisor. All approvals and/or issue dates of the original group procedure are maintained for present use.

15.2.7 Lockout Procedure for the Yellow IR Quadrupole Stand Alone Nested Power Supplies or QPA's During Running Periods When a Power Supply Must be Repaired

Text Pages 3 through 6

Appendices Pages 7 through 12

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: _____ ***Signature on File*** _____
Collider-Accelerator Department Chairman Date

D. Bruno



Procedure: C-A-CPS-007
Revision: 02
Revision Date: 01/11/07

COLLIDER-ACCELERATOR DEPARTMENT

Title: Lockout Procedure for the Yellow IR Quadrupole Stand Alone Nested Power Supplies or QPA's During Running Periods when a Power Supply Must be Repaired

Author: D. Bruno

Group: Collider Power Supply

Group Leader concurrence indicates procedure is still current.

Group Leader: Donald Bruno *Signature on File* Date: 1/11/07

**This Procedure Must Be Reviewed By The Technical Supervisor Prior to use.
If This Procedure Does Not Reflect Current Equipment/Processes
Then Immediately Notify The Group Leader**

Lockout Procedure for the Yellow IR Quadrupole Stand Alone Nested Power Supplies or QPA's During Running Periods When a Power Supply Must be Repaired

1. Purpose

- 1.1 This procedure provides instructions to the Collider Electrical Power Supply Group (CEPSG) technicians and the Collider-Accelerator Support (CAS) technicians on the proper lockout that must be done before you repair a stand alone nested Yellow IR quadrupole power supply (p.s.) or QPA.

Caution:

This lockout procedure can only be used in preparation to repair a Stand alone Nested Yellow IR Quadrupole P.S. or QPA during running periods. See Appendix 1 for a complete list of the sitewide names of these Stand alone Nested Yellow IR Quadrupole P.S's and QPA's. If the sitewide name of the Yellow p.s. or QPA that must be repaired is on the list in Appendix 1 then you can use this procedure.

- 1.2 C-A Policy states that the preferred method to protect workers from energy sources is Lockout-Tagout (LOTO). There is no need to place a tag on the lock if the lock will not stay on past 1 shift or overnight as is consistent with standard LOTO Procedures.
- 1.3 Running Periods are defined as those periods when the C-A Main Control Room (MCR) has a scheduled operator on watch 24 hours a day and beam is being delivered or beam is being prepared to be delivered to RHIC.

2. Responsibilities

- 2.1 Responsibilities of the CEPSG and CAS Technicians
- 2.1.1 Any CEPSG and CAS Technicians preparing to repair a Stand alone Nested Yellow IR Quadrupole P.S. or QPA shall apply their lock, as described in section 5, to assure their own safety.
- 2.2 Responsibilities of System Specialists
- 2.2.1 System Specialists are responsible for training the CEPSG and CAS Technicians.

3. Prerequisites for the CEPSG and CAS Technicians

- 3.1 The CEPSG and CAS Technicians must be trained in LOTO.
- 3.2 The CEPSG and CAS Technicians must be trained in the use of this procedure and their name must appear on a list maintained by Don Bruno and Bill Anderson. This list is attached in Appendix 3 and will be updated as more people are trained. The training is valid for 1 year.

- 3.3 The CEPSG and CAS Technicians must be trained in Electrical Safety.
- 3.4 The CEPSG and CAS Technicians must wear leather gloves, safety glasses, natural fiber long sleeve shirt and natural fiber long pants when using this procedure for class 0+ hazards. If the hazard is a class 2 then the CEPSG and CAS Technicians must wear cotton underwear, fire retardant long-sleeve shirt and long pants, hardhat with arc rated face shield, safety glasses, leather gloves, leather shoes and hearing protection. If the hazard is a class 4 then the CEPSG and CAS Technicians must wear cotton underwear, FR long-sleeve shirt and FR long pants, hardhat, safety glasses, leather gloves, leather shoes and hearing protection plus multilayer flash suit, and flash suit hood.

4. **Precautions for the CEPSG and CAS Technicians**

- 4.1 If the repair of the Nested Yellow IR Stand alone Quadrupole p.s. is in the DC compartment or if you must work on the isolation amplifier board then this procedure must be used. See Figure 1 in Appendix 2 for a photo of the location of the isolation amplifier board. The isolation amplifier board has a cover on it which is not shown in Figure 1. If the repair is in the upper front AC compartment then you can just lockout the 480VAC to the p.s. Turning off the 480V circuit breaker on the front of the p.s. is a class 2 hazard and locking out the 480VAC disconnect, that feeds this p.s., is a class 4 hazard. Verifying the 480VAC is locked out is a class 4 hazard.
- 4.2 If the repair is in the lower front control compartment then you can just lockout the 480VAC to the p.s. because the isolation amplifier board is covered. See Figure 1 in Appendix 2 for a photo of the location of the isolation amplifier board (cover not shown). The lower front control compartment does not contain 480VAC. It does contain 110VAC but it goes through a control transformer. Verifying the 110VAC is not present, after locking out the 480VAC disconnect, is considered a class 0+ hazard. Locking out the 480Vac breaker on the p.s. is a class 2, on the wall, the disconnect is a class 4.

5. **Procedure**

- 5.1 If you must repair a Stand alone Nested Yellow IR Quadrupole P.S. or QPA then write down the name of this p.s. here: _____
- 5.2 Next consult the Appendix 1 and make sure the name is in the appendix. You have now confirmed that this p.s. or QPA is a Stand alone Nested Yellow IR Quadrupole P.S. or QPA

Warning:

If this p.s. does not appear in Appendix 1 then STOP and consult the engineer.

- 5.3 Make sure the Yellow link is down before performing this lockout. MCR can tell you if the link is down. If MCR says the link is not down then tell them you will bring the link down.
- 5.4 Get a lock and go out and look at the p.s. or QPA that must be repaired. See Appendix 1 to find out which building the p.s. or QPA is in. At the top of the p.s. is a “rack” name even though the p.s. is not in a rack. Write down the building and rack name here:
Building _____
Rack Name _____
- 5.5 If the Yellow link is not down then tell MCR you will be bringing the link down but they must run all of the p.s.’s to zero current first.
- 5.6 Once the p.s.’s are at zero current you should put the p.s. that must be repaired into LOCAL and STANDBY from the front panel controls. Now put it in the OFF state. Use the OFF pushbutton on the front of the p.s. to do this. The Yellow link will now come down if it is not down already. If a QPA is being repaired do the same thing to its associated p.s.
- 5.7 Now that the p.s. is in the OFF state you can turn OFF the circuit breaker on the front of this p.s. (class 2).
- 5.8 Lockout the 480VAC disconnect (class 4) that feeds this p.s. Check off that it has been locked out here:
_____ (Locked out 480VAC Disconnect)
- 5.9 Go to service building 1004B and turn off the following Yellow main quadrupole power supplies control switches (class 0+) (next step is lockout):
PYQR _____ (CHECK AFTER TURNED OFF)
PYQFT _____ (CHECK AFTER TURNED OFF)
- 5.10 You turn off these main p.s.’s out by turning the red front panel switch to the left. Watch that the lights on the control chassis go off. See Appendix 2 Figure 2 for a photo of the switch.
- 5.11 Before locking out the 480V disconnects observe 480V on all three line to line voltages on the volt meters on the front of the power supplies. Next, make sure all of the lights are flashing on the voltage monitor gauges on the back of the p.s. After you lock out the 480V disconnect switch make sure all three line to line voltages on the volt meters on the front of the power supplies read zero. Next make sure all of the lights are flashing are OFF on the voltage monitor gauges on the back of the p.s.

- 5.12 In 1004B lockout the following Yellow main quadrupole power supplies 480V disconnect switches (class 4). These 480V switches are located along the building parking lot wall. See Appendix 2 Figure 3. These have kirklocks so take the key with you after the switch is locked out:
SYQR_____ (CHECK AFTER LOCKED OUT)
SYQFT_____ (CHECK AFTER LOCKED OUT)
- 5.13 After you have completed repairing the p.s. or QPA you can now unlock the 480VAC disconnect (class 4) for the p.s. you were working on and turn ON the circuit breaker on the stand alone p.s.
- 5.14 Next, you can now unlock the main p.s.'s and then restore the regulator to operational conditions. Restore the main p.s. regulator by following this procedure: <http://www.c-ad.bnl.gov/ceps/files/pdf/Unlock%20and%20Restore%20MPS.pdf>
- 5.15 If there is a problem getting the above link to work in 5.14 then the procedure in 5.14 is called "Unlocking and Restoring Main Power Supplies". It can be found by going to this web page: <http://www.c-ad.bnl.gov/ceps/Mains.htm>
- 5.16 Once you are done restoring the regulator for the main p.s.'s, tell MCR that they can now bring up the Yellow link up.

Appendix 1

NESTED RHIC IR YELLOW Stand Alone Quadrupole Power Supplies

BUILDING 1002B	
P.S. Name	Rack Number
Y2-Q7-PS	R2BYQF5
BUILDING 1004B	
P.S. Name	Rack Number
YO4-QD7-PS	R4BYQF6
YI3-QF7-PS	R4BYQF5
Y-QTRIM-PS	R4BOFF2
BUILDING 1006B	
P.S. Name	Rack Number
Y6-Q7-PS	R6BYQF5
BUILDING 1008B	
P.S. Name	Rack Number
Y8-Q7-PS	R8BYQF5
BUILDING 1010A	
P.S. Name	Rack Number
YO9-QD7-PS	R10AYQF5
YI10-QF7-PS	R10AYQF6
BUILDING 1012A	
P.S. Name	Rack Number
Y12-Q7-PS	R12AYQF5

Appendix 1 (continued)
NESTED RHIC IR Stand Alone Quadrupole QPA's

BUILDING 1002B	
QPA Name	Rack Number
Y2-Q7-QP	R2BYQF5
BUILDING 1004B	
QPA Name	Rack Number
YO4-QD7- QP	R4BYQF6
YI3-QF7- QP	R4BYQF5
Y-QTRIM- QP	R4BOFF2
BUILDING 1006B	
QPA Name	Rack Number
Y6-Q7- QP	R6BYQF5
BUILDING 1008B	
QPA Name	Rack Number
Y8-Q7- QP	R8BYQF5
BUILDING 1010A	
QPA Name	Rack Number
YO9-QD7- QP	R10AYQF5
YI10-QF7- QP	R10AYQF6
BUILDING 1012A	
QPA Name	Rack Number
Y12-Q7- QP	R12AYQF5

Appendix 2



Figure 1: Photo of Isolation Amplifier board in lower front Control Compartment of Stand Alone p.s. There is a cover over the isolation amplifier board that is not shown here.

The RED arrow is pointing at the isolation amplifier board.

Appendix 2 (continued)



Figure 2: Photo of one RED Front Panel Switch for the PYQFT Main p.s.

The Red Arrow is pointing to the RED switch you must turn off for the main p.s. PYQFT

The Black Arrow is pointing to the label that tells you which p.s. this is.

Appendix 2 (continued)



Figure 3: 480V disconnect switches for main quadrupole p.s.'s along parking lot wall

Appendix 3

Lockout Procedure For the Yellow IR Quadrupole Stand alone Nested Power Supplies During Running Periods When a Power Supply Must be Repaired

List of People Trained. Training is valid for 1 year

Name	Date Trained