

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are available by contacting the ESSHQ Procedures Coordinator, Bldg. 911A*

C-A OPERATIONS PROCEDURES MANUAL

15.3.1.5 AGS Sextupole Magnet Coil Test Procedure

(Booster/AGS Ring Power Supply Systems Group Procedure EPS-A-001)

Note: This document was formerly a C-A Group Procedure. The content of the group procedure was reviewed by the Technical Supervisor. All approvals and/or issue dates of the original group procedure are maintained for present use.

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: Signature on File  
Collider-Accelerator Department Chairman      Date

M. Bannon

Booster/AGS Ring Power Supply Systems  
Group Procedure EPS-A-005  
Revision 00

### 15.3.1.5 AGS SEXTUPOLE MAGNET COIL TEST PROCEDURE

**EQUIPMENT REQUIRED:** *BIDDLE 500VDC MEGGER-CATALOG #210800*  
*ROD-L ELECTRONICS HIPOT TESTER-MODEL M100DC*  
*AGS PSG RINGER- #2*  
*TEKTRONIX ISOLATION PROBES-MODEL #P5200*  
*LECROY OSCILLISCOPE W/PRINTER*  
*HEAVY DUTY ALUMINUM FOIL*  
*GROUNDING STICK*  
**HIGH VOLTAGE RUBBER GLOVES**  
**SAFETY GLASSES**

**NOTE: HIGH VOLTAGE RUBBER GLOVES MUST BE WORN FOR MEGGER AND HIPOT TESTING**

#### A) MEGGER TEST

Tightly wrap the entire coil in **ALUMINUM FOIL** leaving about ½” between foil and conductor at the ends.

Short both ends of coil to each other.

Connect the **POSITIVE** lead of the **MEGGER** to one end of the coil.

Connect the **NEGATIVE** lead of the **MEGGER** to the foil.

Turn **MEGGER** on for 30 seconds and record the resistance on the **COIL EVALUATION SHEET**.

#### B) HIPOT TEST

With the coil still wrapped and the ends still shorted,

Connect the **POSITIVE** lead of the **HIPOTTER** to one end of the coil.

Connect the **NEGATIVE** lead of the **MEGGER** to the foil.

Turn the **HIPOTTER** on for 1 minute and record leakage current on **COIL EVALUATION SHEET**.

#### C) PULSE CHECK (COIL RINGING)

**NOTE: COIL MUST BE OUT OF STEEL AND NOT ON A METAL TABLE. USE A LECROY SCOPE WITH A TEKTRONIX ISOLATION PROBE AND PRINT A COPY TO INCLUDE WITH THE COIL EVALUATION SHEET.**

Unwrap coil and remove short across the ends.

Set up the **DC POWER SUPPLY** for **10VDC**.

Connect the **POSITIVE** lead of the **RINGER AND ISOLATION PROBE** to one end of the coil.

Connect the **NEGATIVE** lead of the **RINGER AND ISOLATION PROBE** to the other end of the coil.

Turn on the **DC POWER SUPPLY**.

Turn on the **RINGER**.

Push the **RED TRIGGER BUTTON** on the **RINGER** to ring the coil, and capture it on the **SCOPE**.

Print out the result and attach it to the **COIL EVALUATION SHEET**.