If you are using a printed copy of this procedure, and not the on-screen version, then you MUST make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.

Hard copies of all signed, official, C-A Operating Procedures are available by contacting the ESSHQ Procedures Coordinator, Bldg. 911A

C-A OPERATIONS PROCEDURES MANUAL

15.3.3.27 Emergency Procedure @ Bldg .928

(Booster/AGS Ring Power Supply Systems Group Procedure EPS-S-027)

Note: This document was formerly a C-A <u>Group</u> Procedure. The content of the group procedure was reviewed by the Technical Supervisor. All approvals and/or issue dates of the original group procedure are maintained for present use.

Text Pages 3 through 3

Hand Processed Changes

HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>
	Approved:Collide	Signature on File er-Accelerator Department Cha	irman Date

M. Bannon

Group Procedure EPS-S-027 Revision 00

Emergency Procedure in Bldg. 928

Should a situation occur where it is deemed necessary to stop the AGS MMPS from pulsing and stop the MG Set from spinning the following steps should be performed.

Press the PL9 push button located on LE1 - by first lifting up the protective cover and press the push button underneath the cover. A PL9 should systematically turn off the rectifiers. Turn off the Cycloconverter and switch to liquid Rheostat, turn the motor off and then apply the motor brake and bring the set to a stop, then turn off the auxiliaries.

Some examples when to turn the MG Set off for Emergencies are:

- 1) FIRE ALARM IN BLDG 928 The Smell of Smoke / Seeing Fire. (Note: There is a Halon System in old control room, if it goes off the room will be deprived of oxygen which will cause someone who is in the room to pass out and cause severe harm to that individual. Therefore leave building if fire alarm occurs.)
- 2) Sever oil leak from the MG Set.