

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are available by contacting the ESSHQ Procedures Coordinator, Bldg. 911A*

C-A OPERATIONS PROCEDURES MANUAL

16.4.18 EAGAL Mask Modifications

(Collider Accelerator Support Group Procedure A.18.0)

Note: This document was formerly a C-A Group Procedure. The content of the group procedure was reviewed by the Technical Supervisor. All approvals and/or issue dates of the original group procedure are maintained for present use.

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: _____ Signature on File _____
 Collider-Accelerator Department Chairman Date

D. Phillips

Collider Accelerator Support Group
Procedure A.18.0
Original Issue Date: 01/26/04
Revision 00

FES PROCEDURES AND INSTRUCTIONS

Date: 1/26/04

Issued By: D. Phillips

Subject: EAGAL Mask Modifications

1. **Purpose:**

- 1.1 Provide a method for updating EAGAL Masks.

2. **Responsibilities:**

- 2.1 CAS and FES personnel using these programs are responsible for the implementation of this procedure.

3. **Prerequisites:**

- 3.1 Basic knowledge of Windows and the RS Logix 500.

4 **Precautions:**

- 4.1 Incorrectly masking alarms can have serious consequences for operations.

5. **Procedures:**

- 5.1 Retrieve the most recent version of the EAGAL excel tables from \\c-adfile3\plccas\excel\eagal
- 5.2 Mark in red the masks to be changed.
- 5.3 Have sheet approved by LE for related beam line or by D. Phillips.
- 5.4 After approval use RS Logix 500 to update the Mask bits in question in the "eagal.rss" program in the EAGAL SLC.
- 5.5 Check-off each Mask on the excel table as it is changed. 5.6 Save program to the Lap Top computer.
- 5.7 Store the program to the eeprom memory in the SLC.
- 5.8 E-mail a copy of the modified program to D. Phillips.
- 5.9 Send the copy of the excel table with the checked-off modifications to D. Phillips.

6. Documentation:

6.1 When applicable, the completed work order.

6.2 When applicable, record an entry in the CAS Watch Log.

7. Reference:

7.1 None

8. Attachments:

8.1 None