

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match.  
The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.  
Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A.*

## C-A OPERATIONS PROCEDURES MANUAL

### 7.1.20 Adsorber Bed B Online and Adsorber Bed A Offline Procedure

Text Pages 2 through 4

#### Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: \_\_\_\_\_ *Signature on File* \_\_\_\_\_  
 Collider-Accelerator Department Chairman Date

S. Sakry

## **7.1.20 Adsorber Bed B Online and Adsorber Bed A Offline Procedure**

### **1. Purpose**

This procedure provides instructions for placing adsorber bed B online and taking adsorber bed A offline. This procedure will be performed when adsorber bed A is contaminated and being taken offline for regeneration. The steps necessary to regenerate adsorber bed A are not covered under this procedure, please reference [C-A OPM 7.1.21](#).

### **2. Responsibilities**

- 2.1 The Shift Supervisor, or an Operator designated by the Shift Supervisor, is responsible for conducting the procedure and providing documentation in the Cryogenic Control Room Log and in the Cryogenic Valve Log.
- 2.2 Should a problem arise in the process of regenerating the adsorber bed, the Shift Supervisor shall report to the Technical Supervisor for instructions before continuing.

### **3. Prerequisites**

- 3.1 The Operator shall be trained by the Shift Supervisor.
- 3.2 Operator shall be familiar with the refrigerator P&ID drawing 3A995009, the physical location of components on the refrigerator, and the refrigerator control pages found on the CRISP control system. Valves and equipment mentioned in this procedure will be found on drawing 3A995009.
- 3.3 Adsorber Bed "B" has been regenerated per [C-A-OPM 7.1.22 "Regeneration of Adsorber Bed "B"'](#). Adsorber Bed "B" is clean and ready for service if inlet valve H762A is open and outlet valve H771A is closed.
- 3.4 The oxygen monitor and hygrometer in the compressor room shall be set to read the compressor discharge.

### **4. Precautions**

- 4.1 If there is liquid helium in the refrigerator pots, all personnel entering the refrigeration wing of 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM), and carry an emergency escape pack.

## 5. Procedure

- \_\_\_\_\_ 5.1 Date \_\_\_\_\_
- \_\_\_\_\_ 5.2 Ensure instrument valve H765M is closed.
- \_\_\_\_\_ 5.3 Ensure instrument valves H843M\_\_\_\_\_ and H770M\_\_\_\_\_ are open.
- \_\_\_\_\_ 5.4 Ensure closed valves H9093M\_\_\_\_\_ V263M\_\_\_\_\_ and H897M\_\_\_\_\_.
- \_\_\_\_\_ 5.5 Open valves H898M\_\_\_\_\_ and H9092M\_\_\_\_\_.
- \_\_\_\_\_ 5.6 Crack open valve H899M.
- \_\_\_\_\_ 5.7 Monitor TI769H, adjust valve H899M, as needed, to achieve a temperature drop of approximately 15°K/10 minutes.
- \_\_\_\_\_ 5.8 Open valve H7771A when TI769H is within 10°K of TI369H and below 100°K.
- \_\_\_\_\_ 5.9 Should any sustained increase in the O2 or H2O monitors at the compressor discharge appear, stop this procedure and regenerate adsorber "B" as per [C-A-OPM 7.1.22](#).
- \_\_\_\_\_ 5.10 Close valves H898M\_\_\_\_\_ and H899M\_\_\_\_\_.
- \_\_\_\_\_ 5.11 Close valve H371A when TI769H and TI369H are equal and stable.
- \_\_\_\_\_ 5.12 Close valve H362A.
- \_\_\_\_\_ 5.13 Enable logic alarm on adsorber bed "B".
- \_\_\_\_\_ 5.14 Open valve H9089M.
- \_\_\_\_\_ 5.15 Crack open valve H9090M to vent adsorber.
- \_\_\_\_\_ 5.16 When adsorber "A" is at approximately 10 atm, close valve H9090M.

- \_\_\_\_\_ 5.17 When thawed, close valves H9092M\_\_\_\_\_ and H9089M\_\_\_\_\_.
- \_\_\_\_\_ 5.18 If adsorber bed "A" was taken off line due to contamination, start regeneration process as specified in [C-A-OPM 7.1.21](#).

## 6. **Documentation**

- 6.1 The check-off lines on the procedure are for place-keeping only. The procedure is not to be initialed or signed, it is not a record.
- 6.2 The Shift Supervisor shall document the completion of the procedure in the Cryogenics Control Room Log.

## 7. **References**

- 7.1 Drawing 3A995009, 25kW Helium Refrigerator P&ID.
- 7.2 [C-A-OPM 7.1.21](#), "Regeneration of Adsorber Bed "A".
- 7.3 [C-A-OPM 7.1.22](#), "Regeneration of Adsorber Bed "B".

## 8. **Attachments**

None