

*Official copies of these procedures are maintained at this website.  
Before using a printed copy, verify that it is the most current  
version by checking the document issue date on this website. Signed  
copies of these official procedures are maintained at the Training Office.*

## C-A OPERATIONS PROCEDURES MANUAL

### 7.1.22 Regeneration of Adsorber Bed B

Text Pages 2 through 4

#### Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: Signature on File  
Collider-Accelerator Department Chairman      Date

S. Sakry

## 7.1.22 Regeneration of Adsorber Bed B

### 1. Purpose

This procedure provides instructions for regenerating adsorber bed B on the RHIC 25 kW Helium Refrigerator. This procedure shall be performed when adsorber bed B is contaminated and has been taken offline. The steps necessary to take adsorber bed B offline are not covered under this procedure, please reference [C-A OPM 7.1.19](#).

### 2. Responsibilities

- 2.1 The Shift Supervisor, or an Operator designated by the Shift Supervisor, is responsible for conducting the procedure and providing documentation in the Cryogenic Control Room Log and in the Cryogenic Valve Log.
- 2.2 Should a problem arise in the process of regenerating the adsorber bed, the Shift Supervisor shall report to the Technical Supervisor for instructions before continuing.

### 3. Prerequisites

- 3.1 The Operator shall be trained by the Shift Supervisor.
- 3.2 Operator shall be familiar with the refrigerator P&ID drawing 3A995009, the physical location of components on the refrigerator, and the refrigerator control pages found on the CRISP control system. Valves and equipment mentioned in this procedure will be found on drawing 3A995009.
- 3.3 The regeneration skid must be available for use.

### 4. Precautions

- 4.1 If there is liquid helium in the refrigerator pots, all personnel entering the refrigeration wing of 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM), and carry an emergency escape pack.

### 5. Procedure

\_\_\_\_\_ 5.1 Date \_\_\_\_\_

\_\_\_\_\_ 5.2 Ensure the following valves are CLOSED:

Process Valves:

H762A\_\_\_\_\_ H771A\_\_\_\_\_

Valves Used for Regeneration/Pure Helium:

H817M\_\_\_\_\_ H9120M\_\_\_\_\_

Valves to atmosphere, relief valve header, sample taps or vacuum:

H766M\_\_\_\_\_ H898M\_\_\_\_\_ H9093M\_\_\_\_\_  
H767M\_\_\_\_\_ H899M\_\_\_\_\_ H9121M\_\_\_\_\_  
H768M\_\_\_\_\_ H9092M\_\_\_\_\_ V263M\_\_\_\_\_

- \_\_\_\_\_ 5.3 Start the regeneration (regen) skid per [C-A-OPM 7.1.36](#), "Regeneration System Normal Operation".
- \_\_\_\_\_ 5.4 Open the following valves:
- H163M\_\_\_\_\_ H9091M\_\_\_\_\_  
H818M\_\_\_\_\_ H9173M\_\_\_\_\_  
H819M\_\_\_\_\_
- \_\_\_\_\_ 5.5 Close regen manifold bypass valve H9100M.
- \_\_\_\_\_ 5.6 Turn on regen skid pre-heater.
- \_\_\_\_\_ 5.7 Monitor sensor TI769.
- \_\_\_\_\_ 5.8 When the TI769 reaches 310°K, continue to regenerate for at least 1 hour. Hygrometer reading must be -20°C to -40°C and improving less than 0.5°C/hr.
- \_\_\_\_\_ 5.9 Turn off regen skid preheater.
- \_\_\_\_\_ 5.10 Open valve H9100M.
- \_\_\_\_\_ 5.11 Close the following valves:
- H9091M\_\_\_\_\_ H818M\_\_\_\_\_  
H819M\_\_\_\_\_ H163M\_\_\_\_\_  
H9173M\_\_\_\_\_
- \_\_\_\_\_ 5.12 Secure the regeneration skid per [C-A-OPM 7.1.36](#).
- \_\_\_\_\_ 5.13 Set up to purge adsorber bed "B" by opening H9120M\_\_\_\_\_ and H9092M\_\_\_\_\_.

- \_\_\_\_\_ 5.14 Crack open valves H817\_\_\_\_\_ and H9093M\_\_\_\_\_ until an audible purge is heard.
- \_\_\_\_\_ 5.15 Align oxygen monitor to sample valve H768M.
- \_\_\_\_\_ 5.16 Allow adsorber bed "B" to purge for approximately 3 hours at an audible level. Oxygen monitor reading must be less than 10 ppm.
- \_\_\_\_\_ 5.17 Close valves H9093M\_\_\_\_\_ and H9092M\_\_\_\_\_.
- \_\_\_\_\_ 5.18 When PI845H reaches approximately 250 PSIA, close valves H817M\_\_\_\_\_ and H9120M\_\_\_\_\_.
- \_\_\_\_\_ 5.19 Open inlet valve H762A as a sign that adsorber bed "B" has been regenerated and is ready for service.

## 6. **Documentation**

- 6.1 The check-off lines on the procedure are for place-keeping only. The procedure is not to be initialed or signed, it is not a record.
- 6.2 The Shift Supervisor shall document the completion of the procedure in the Cryogenics Control Room Log

## 7. **References**

- 7.1 Drawing 3A995009, 25KW Helium Refrigerator P&ID.
- 7.2 [C-A-OPM 7.1.19](#), "Adsorber Bed "A" Online and Adsorber Bed "B" Offline.
- 7.3 [C-A-OPM 7.1.36](#), "Regeneration System Normal Operation".

## 7. **Attachments**

None