If you are using a printed copy of this procedure, and not the on-screen version, then you <u>MUST</u> make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.

Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ

Training Office, Bldg. 911A.

C-A OPERATIONS PROCEDURES MANUAL

\neg	1		D	CXXI	Tr 1 '	11 A 11	Tr •
1	1	. h /	Regeneration	or warm	Lurbines	·· A ··	I rain

Text Pages 2 through 10

Hand Processed Changes

HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>	
	Approved: _	Signature on File		
		Collider-Accelerator Depart	ment Chairman Da	ate

S. Sakry

7.1.57 Regeneration of Warm Turbines "A" Train

1. Purpose

To provide instructions for regenerating the warm turbine "A" train on the RHIC 25 kW helium refrigerator. The procedure is used to warm the turbines and remove moisture. The procedure contains the following sections:

- 5.1 Regeneration of Turbines 1A/2A Only.
- 5.2 Regeneration of Turbines 3A/4A Only.
- 5.3 Regeneration of HX3A Only.
- 5.4 Regeneration of Turbines 1A/2A, 3A/4A and Heat Exchanger HX3A.

2. Responsibilities

- 2.1 The Shift Supervisor, or an Operator designated by the Shift Supervisor, is responsible for conducting the procedure and providing documentation in the Cryogenic Control Room Log and in the Cryogenic Valve Log.
- 2.2 Should a problem arise in the process of the procedure, the Shift Supervisor shall report to the Technical Supervisor for instructions before continuing.

3. Prerequisites

- 3.1 The Operator shall be trained by the Shift Supervisor.
- 3.2 Operator shall be familiar with the refrigerator P&ID drawing 3A995009, the physical location of components on the refrigerator, and the refrigerator control pages found on the CRISP control system. Valves and equipment mentioned in this procedure will be found on drawing 3A995009.
- 3.3 The regeneration skid must be available for use.

4. <u>Precautions</u>

4.1 If there is liquid helium in the refrigerator pots, all personnel entering the refrigeration wing of 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM), and carry an emergency escape pack, if the refrigerator is operating.

5. <u>Procedure</u>

5.1	<u>Turbin</u>	ines 1A/2A Only		
	5.1.1	Date		
	5.1.2	Ensure mechanical brakes are installed per <u>C-A-OPM 7.1.26</u> , " <u>Expander Brake System Installation and Removal.</u> "		
	5.1.3	3 Ensure the following valves are closed:		
<u>Process</u> :		<u>Process</u> :		
		H328A H338M		
		Other:		
		H407M H400M H703M H773M H9171M		
	5.1.4	Start the regeneration (regen) skid per <u>C-A OPM 7.1.36</u> , " <u>Regeneration</u> <u>System Normal Operation</u> ."		
	5.1.5	Ensure that the regulator PR9169M has been replaced with the spool piece.		
	5.1.6	Open the following valves:		
		H405M H243M H266M H330A (Vanes) H9169M H339A (Vanes) H373M		
	5.1.7	Close regen manifold bypass valve H9100M.		
	5.1.8	If turbine train is cold, turn on regen skid pre-heater.		
	5.1.9	Monitor temperature at TI337H.		
	5.1.10	10 When TI337H reaches 290°K, continue to regenerate for at least one hour. Hygrometer reading must be -20°C to -40°C and improving less than 0.5°C/hour.		

3

	5.1.11	Turn off regen skid pre-heater.		
	5.1.12	Open bypass valve H9100M.		
	5.1.13	Close the following valves:		
		H330A H9169M H339A H266M H243M H405M H373M		
	5.1.14	Secure the regen skid per <u>C-A OPM 7.1.36</u> .		
	5.1.15	Install regulator PR9169M.		
	5.1.16	Purge expander 1A/2A per <u>C-A OPM 7.1.27</u> , "Warm Expander Purge <u>Procedure."</u>		
5.2	<u>Turbin</u>	es 3A/4A Only		
	5.2.1	Date		
	5.2.2	Ensure mechanical brakes are installed on turbines 3A/4A per <u>C-A OPM 7.1.26</u> , "Expander Brake System Installation and Removal."		
	5.2.3	Ensure the following valves are closed:		
		<u>Process</u> :		
		H352A H380A H360M		
		Other:		
		H429M H9177M H777M H427M H6182M H778M		
	5.2.4	Start the regeneration (regen) skid per <u>C-A OPM 7.1.36</u> , " <u>Regeneration</u> <u>System Normal Operation</u> ."		
	5.2.5	Ensure that regulator PR9175M has been replaced with the spool piece.		

	5.2.6	Open the following valves:	
		H377M	H415M H354A (Vanes) H357A (Vanes)
	5.2.7	Close regen skid bypass valve	H9100M.
	5.2.8	If turbine train is cold, turn on	regen skid pre-heater.
	5.2.9	Monitor turbine 4A outlet tem	perature at TI361H.
	5.2.10		continue to regenerate for at least one hour. –20°C to –40°C and improving less than
	5.2.11	Turn off regen skid pre-heater	
	5.2.12	Open bypass valve H9100M.	
	5.2.13	Close the following valves:	
		H357A	H9175M H377M H428M
	5.2.14	Secure the regen skid per <u>C-A</u> <u>Normal Operation."</u>	OPM 7.1.36, "Regeneration System
	5.2.15	Install regulator PR9175M.	
	5.2.16	Purge expanders 3A/4A per C Procedure."	-A OPM 7.1.27, "Warm Expander Purge
5.3	Heat E	xchanger HX3A Only	
	5.3.1	Date	
	5.3.2		installed on turbines 1A/2A and 3A/4A per Brake System Installation and Removal."

 5.3.3	Ensure the following valves are closed:	
	<u>Process</u> :	
	H330A (Vane) H339A (Vane) H354A (Vane) H357A (Vane) H344A H341M	H376M H346M H426M H380A (Physically Block) H328A (Physically Block)
	Other:	
	H429M H6182M H777M	H9177M H400M H773M
 5.3.4	Start the regeneration (regen) System Normal Operation."	skid per <u>C-A OPM 7.1.36</u> , "Regeneration
 5.3.5	Ensure that regulator PR9175	M has been replaced with the spool piece.
 5.3.6	To avoid spinning turbines, en equal to pressure in expander	nsure pressure in HX3A is approximately s (with 0.5 atm).
 5.3.7	Open process valves H338M_jumpered at valve).	and H352A (air line must be
 5.3.8	Open the following valves:	
	H428M H377M H9175M	H373M H243M
 5.3.9	Close regen skid bypass valve	е Н9100М.
 5.3.10	If heat exchanger is cold, turn	on regen skid pre-heater.
 5.3.11	Monitor regen return line at v	alve H373M.
 5.3.12		the regen return line, continue to regen for at eading must be -20° C to -40° C and ur.

5.5.15	Turn off regen skid pre-heater.		
5.3.14	Open bypass valve H9100M.		
5.3.15	Close the following valves:		
	H243M H373M H9175M	H377M H428M	
5.3.16	Install regulator PR9175M.		
		Note: ating, heat exchanger and turbines are ly due to heat transfer between HX3	
5.3.17	Purge heat exchanger HX3A Purge Procedure."	per C-A OPM 7.1.27, "Warm Expander	
	Purge Procedure."	per <u>C-A OPM 7.1.27, "Warm Expander</u> C-A OPM 7.1.27, "Warm Expander Purge	
5.3.18	Purge Procedure." Purge expanders 1A/2A per Carre Procedure."	-	
5.3.18 5.3.19	Purge Procedure." Purge expanders 1A/2A per Control Procedure." Purge expanders 3A/4A per Control Procedure.	C-A OPM 7.1.27, "Warm Expander Purge C-A OPM 7.1.27, "Warm Expander Purge	
5.3.18 5.3.19	Purge Procedure." Purge expanders 1A/2A per Carrocedure." Purge expanders 3A/4A per Carrocedure."	C-A OPM 7.1.27, "Warm Expander Purge C-A OPM 7.1.27, "Warm Expander Purge valves are closed:	

7

5.4 <u>Turbines 1A/2A, 3A/4A and Heat Exchanger HX3A</u>

This section is normally completed only when the refrigerator is shut down due to heat transfer between HX3 heat exchangers.

 5.4.1	Date	·
 5.4.2		s are installed on turbines per <u>C-A OPM</u> em Installation and Removal."
 5.4.3	Ensure the following valves are closed:	
	<u>Process</u> :	
	H328A H346M H376M	H426M H360M H380A
	Others:	
	H407M H703M H9171M H373M H6179M	H6180M H9175M H427M H778M
 5.4.4	Start the regeneration (regen) <u>System Normal Operation."</u>	skid per <u>C-A OPM 7.1.36</u> , "Regeneration
 5.4.5	Ensure that the regulator PR9 piece.	169M has been replaced with the spool
 5.4.6	To avoid spinning turbines, en equal to pressure in expanders	nsure pressure in HX3A is approximately s (within 0.5 atm).
 5.4.7	Open process valves H338M_iumpered at valve).	and H352A (air line must be

	5.4.8	Open the following valves:		
		H405M H266M H6169M H378M H415M	H330A (Vanes) H339A (Vanes) H354A (Vanes) H357A (Vanes)	
:	5.4.9	Close regen manifold bypass	valve H9100M.	
:	5.4.10	If turbine train is cold, turn o	n regen skid pre-heater.	
:	5.4.11	Monitor turbine 4A outlet ter	mperature at TI361H.	
	5.4.12		K, continue to regenerate for at least one hour -20°C to -40°C and improving less than	
:	5.4.13	Turn off regen skid pre-heate	r.	
	5.4.14	Open bypass valve H9100M.		
:	5.4.15	Close the following valves:		
		H357A (Vane) H354A (Vane) H339A (Vane) H330A (Vane) H415M	H378M H6169M H266M H405M	
	5.4.16	Install regulator PR9169M.		
:	5.4.17	Purge expanders 1A/2A, 3A/-7.1.27, "Warm Expander Pur	4A and heat exchanger HX3A per <u>C-A OPM</u> ge <u>Procedure.</u> "	
:	5.4.18	Close the following process v	valves:	
		H352A (Return air line H338M	to normal)	
:	5.4.19	Secure regen skid per <u>C-A O</u> <u>Operation."</u>	PM 7.1.36, "Regeneration System Normal	

6. <u>Documentation</u>

- 6.1 The check-off lines are for place keeping only. The procedure is not to be initialed or signed, it is not a record.
- 6.2 The Shift Supervisor shall document the completion of the procedure in the Cryogenics Control Room Log.

7. <u>References</u>

- 7.1 C-A OPM 7.1.26, "Expander Brake System Installation and Removal"
- 7.2 C-A OPM 7.1.36, "Regeneration System Normal Operation"
- 7.3 C-A OPM 7.1.27, "Warm Expander Purge Procedure"

8. <u>Attachments</u>

None