

*Official copies of these procedures are maintained at this website.  
 Before using a printed copy, verify that it is the most current  
 version by checking the document issue date on this website. Signed  
 copies of these official procedures are maintained at the Training Office*

C-A OPERATIONS PROCEDURES MANUAL

ATTACHMENT

7.1.10.b Initial Valve Configuration

C-A-OPM Procedures in which this Attachment is used.
--

7.1.10		

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: \_\_\_\_\_ **Signature On File** \_\_\_\_\_  
 Collider-Accelerator Department Chairman                      Date

E. Quimby

### Initial Valve Configuration

<u>Valve #</u>	<u>Position</u>	<u>Description</u>	<u>P&amp;ID Location</u>
E2900M	CLOSE	Atmospheric Vent	D6
E2916M	CLOSE	Drain	C5
E2920M	CLOSE	Oil Fill	A5
E2923M	CLOSE	Misc.	C5
E2924M	CLOSE	Misc.	C4
E2925M	CLOSE	Oil Supply Bypass	C3
E2901M	OPEN	PI2901 Isolation	C6
E2903M	OPEN	Coalescer Oil Recovery	D7
E2904M	OPEN	P2904 Isolation	A5
E2905M	OPEN	P2904 Isolation	A4
E2908M	OPEN	P2905 Isolation	B5
E2909M	OPEN	P2905 Isolation	B4
E2911M	OPEN	PS2911 Isolation	B4
E2912M	OPEN	PS2912 Isolation	A4
E2913M	OPEN	SG, LSH, & LSL2915 Isolation	C5
E2914M	OPEN	SG, LSH, & LSL2915 Isolation	C5
E2919M	OPEN	PI2907 Isolation	C3
E2921M	OPEN	Oil Supply	D3
E2922M	OPEN	Oil Recovery Header	D4
H2903M	OPEN	Helium to LP Header	D7
H2904M	OPEN	Helium From HP Header	D6