

Go To: [912-2](#) 912-4 [912-6](#) [912-8](#) [912-F](#)

Alarm Code 912-0
Restore 912-1

Location: C-18 House - B 913-Q

Alarm Limits
Lo Temp ≤ 40 F

System: C-18 Outdoor Piping-Lo Temp

- Action:**
1. Verify that lo temp condition exists
 2. Check that power to heat tracing is on
 - a) If not, turn on circuit
 - b) If on, raise thermostat to energize heat trace
 3. Verify that water flow exists
 - a) If not, check if Fast Quad System is on
 - b) If Fast Quad System is off, Note 3
 4. Note 1 & 3

- Notes:**
1. Record Actions Taken
 2. MCR = Main Control Room (x 4662)
 3. Call Mech Svcs from "Call In" List

[Back to Top](#)

Alarm Code 912-2
Restore 912-3

Location: C-18 House - B 913-Q

Alarm Limits
Lo Flo \leq 2.5 GPM

System: C-18 Water System - Low flo

- Action:**
1. **Verify that low flow exists**

 2. **Check for obstruction, kinked or broken hose in power supply**
 - a) **Isolate if leaking, Note 1 & 3**

 3. **Check that supply and return valves in AGS ring @ C18 sleeve are open.**

 4. **Check that Fast Quad System is on**
 - a) **If off, Note 3**

- Notes:**
1. **Record Actions Taken**
 2. **MCR = Main Control Room (x 4662)**
 3. **Call Mech Svcs from "Call In" List**

[Back to Top](#)

Alarm Code 912-6

Restore 912-7

Location: C-18 House - B 913-Q

Alarm Limits
Hi Temp $\geq 80^{\circ}\text{F}$

System: Building Air Conditing - Hi Temp

- Action:**
1. **Verify Actual Temperature**
 2. **Call AGS A/C Watch during normal working hours or
MMC @ x2468
(ILR# 166942)**
 3. **Call Plant Engineering Site Shift Supervisor at x4174,
cell – 872-8988 or C/W desk x4284 during off hours.**
 4. **Note 2**

- Notes:**
1. **Record Actions Taken**
 2. **MCR = Main Control Room (x 4662)**
 3. **Call Mech Svcs from "Call In" List**

[Back to Top](#)

Alarm Code 912-8
Restore 912-9

Location: Fan House D

Alarm Limits
Hi level

System: A.C. Condensate Receiver - Hi Level

- Action:**
1. **Verify hi level condition**
 2. **Lift float rod on pump alternator**
 3. **If level remains high**
 - a) **Call Plant Engineering Site Shift Supervisor at x4174, cell – 872-8988 or C/W desk x4284 during off hours.**
 - b) **Advise MCR**
 4. **If level drops, Note 1 & 3 the following work day**

- Notes:**
1. **Record Actions Taken**
 2. **MCR = Main Control Room (x 4662)**
 3. **Call Mech Svcs from "Call In" List**

[Back to Top](#)

Alarm Code 912-F
Restore 912-C

Location: Fan House B

Alarm Limits
H₂O level

System: Equipment Pit

- Action:**
1. **Verify a water level exists.**
 2. **Check where the water is coming from
(A/C Condensate or Steam Lines)**
 2. **During normal working hours contact R. Zaharatos
or J. Benante and:**
 - a) **Call MMC @ x2468 (PE) >>Plumber for an A/C
condensate leak or a Steam Fitter for a steam leak.**
 - b) **Call Plant Engineering Site Shift Supervisor at
x4174, cell – 872-8988 or C/W desk x4284 during
off hours.**
 - c) **Advise MCR**

[Back to Top](#)